

Suggestion for tying onto mooring loop

You will need

1. 20 foot warp, minimum 10mm diameter
 2. 6inches length of 20mm diameter tubing
 3. Small lashing string, say 2 ft 3-4mm diameter
 4. Back-up mooring strop for bow eye
-
1. First tie main rope round base of mast and thread through the pole trough
 2. Pick up mooring strop using hand buoy
 3. Temporarily tie onto the mooring loop
 4. Then tie on, or use bow eye connector strop, to tie backup connection from bow eye to mooring loop
 5. Then re-tie the main rope between the mooring strop and the mast base
 6. Tie a lash on the rope in front of the mast to reduce movement, passing the rope through the short section of piping, to prevent chaffing on the mast
 7. Pull the main rope tight enough to take the load off the bow eye

